

INSTRUCTION MANUAL SANITARY LEVEL SWITCH - FLX





Manufactured by:



www.klay-instruments.com

Nijverheidsweg 5 7991 CZ DWINGELOO The Netherlands Tel: +31-521-591550 E-mail: info@klay.nl

H-E-FLX-10-2025-07 Klay Instruments B.V. Page 1

APPLICATION:

The Sanitary, Electronic Level Switch is used for level indication in all liquids with conductivity from infinite to $25 \mu S$. Possible applications are:

- Overfill protection of tanks/vessels
- High and low level signal in tanks
- · Automatic filling and emptying control in tanks
- Registration of conductivity changes in liquids
- Foam detection

LIMITATIONS:


- High-viscous liquids which causes a film (coating) on the sensor.
- In case of very high concentrations of chemical vapours.

DESCRIPTION:

The FLX is based on the well proven technology of measuring the conductivity between the electrode tip and the reference part of the electrode, or tank wall. The level switch is built-into the tank/vessel so that the electrode point is flush with the level to be registered. A weak current is applied between the electrode point and the conductive tank/vessel wall. In non-conductive tanks/vessels a small current is applied between the electrode point and the reference part of the electrode.

As long as the electrode point does not touch the conductive fluid, there will be no current. When the liquid reaches the electrode a weak current is applied. The FLX is available with a PNP output, electronic module SMC-9 and a built in selector switch.

DIMENSIONAL DRAWING:




PARTS DESCRIPTION

1. Cover	AISI 304
2. O-ring	EPDM
3. PG9 Cable Gland	
4. Electronic Housing	AISI 304
5. 1" BSP Nipple, SW 41	AISI 316
6. Sanitary process part	AISI 316
7. Sensor (∅19 mm)	AISI 316
8. Insulation part (Ø19 mm)	PEEK
9. Sensor tip (Ø19 mm)	AISI 316

MATERIAL

H-E-FLX-10-2025-07 Klay Instruments B.V. Page 2



No.	PARTS DESCRIPTION	PART No
1	Cover	10241
2	O-ring	11029
3	PG9 Cable Gland	10138
4	Electronic Housing	10234
5	1" BSP Nipple, SW 41	10272
6	Sanitary process part	10243
7	Sensor (Ø19 mm)	10235
8	Insulation part (Ø19 mm)	20040
9	Sensor tip (Ø19 mm)	10239
10	Treaded Joint	10249
11	O-ring (2x)	11041
12	O-ring (FKM-Viton/EPDM)	11027/11008
13	Connecting Piece	10244
14	Earth Connection	10251
15	O-ring	11042
16	Electronics	192
17	Nut of Synthetic material	20037
18	Seal	20035
19	Type sticker	20523
20	Weld-on nipple (1" BSP)	10197


CONTROL UNIT - SMC-9


TECHNICAL DATA		
Design	Ø 44.50mm	
Operating Voltage	24V(DC)+-20% (18V30V)	
Power Requirements	<30mA	
	-10°C till +70°C	
Storage temperature	-20°C till +85°C	
Humidity	0 till 90% (without condensation)	
Inputs	1 Electrode	
Sensitivity	0,2KOhm; 10KOhm;	
	9,9KOhm999KOhm arbitrary	
Output	1x Electronic output; 30mA;	
	PNP invertible short-circuit-proof	
Time-delay	0,0 up to 99,9sec ; arbitrary	
Start-delay	<0,3s	
Response-time	<0,07s (10KOhm) <0,15s (1MOhm)	




CONFIGURATION				
Switch				
6	5	4	ON	OFF
0	0	0	Adjustable by SMCsoft (Default 2KOhm)	
0	0	1	3KOhm	2.5KOhm
0	1	0	5KOhm	4.5KOhm
0	1	1	6KOhm	5.5KOhm
1	0	0	8KOhm	7.5KOhm
1	0	1	100KOhm	70KOhm
1	1	0	250KOhm	220KOhm
1	1	1	500KOhm	470KOhm

DELAYS			
Swit	ch	Delay in sec.	
3	2		
0	0	(0 sec) adjustable via SMCsoft	
0	1	2 sec	
1	0	4 sec	
1	1	8 sec	





Programming connector !Caution! The lug of the programming connector points to the fastening screw.



When installing or using the device it must be protected from electrostatic discharge. An incorrect installation or parameters which are adjusted incorrectly can interfere with the correct function of your application or can cause damages. Therefore independent safety equipment should be available at any time. Adjustments must only be conducted by qualified personnel. All necessary adjustments are to be made by the configuration switches or the SMC software. If there are difficulties during the start-up, please do not manipulate the device in any incorrect way. Otherwise the warranty expires. If the dewpoint is reached, condensation may destroy the module.